

For vehicles with a navigation system, refer to the “Navigation System Owner’s Manual” for information regarding the equipment listed below.

- Navigation system
  - Air conditioning
  - Rear view monitor system
  - Intuitive parking assist
- Audio/video system
  - Rear window and outside rear view mirror defogging
  - Climate control

1

Before driving

1-1. Key information

Keys ..... 28

1-2. Opening, closing and locking the doors and trunk

Smart access system with push-button start ..... 32

Wireless remote control ..... 43

Doors..... 46

Trunk..... 50

1-3. Adjustable components (seats, mirrors, steering wheel)

Front seats ..... 54

Driving position memory ..... 55

Seat position memory ..... 59

Head restraints..... 61

Seat belts ..... 64

Steering wheel..... 70

Anti-glare inside rear view mirror ..... 72

Outside rear view mirrors..... 74

1-4. Opening and closing the windows and moon roof

Power windows..... 76

Moon roof ..... 79

1-5. Refueling

Opening the fuel tank cap..... 83

1-6. Theft deterrent system

Engine immobilizer system..... 86

Alarm..... 88

Theft prevention labels (U.S.A.)..... 91

1-7. Safety information

Correct driving posture ..... 92

SRS airbags ..... 94

Front passenger occupant classification system..... 106

Child restraint systems ..... 111

Installing child restraints..... 115

## 2 When driving

### 2-1. Driving procedures

Driving the vehicle.....	126
Engine (ignition) switch .....	134
Automatic transmission.....	138
Turn signal lever .....	147
Parking brake .....	148
Horn.....	149

### 2-2. Instrument cluster

Gauges and meters .....	150
Indicators and warning lights.....	154
Multi-information display .....	157

### 2-3. Operating the lights and windshield wipers

Headlight switch.....	162
Fog light switch .....	166
Windshield wipers and washer.....	168
Headlight cleaner switch .....	172

### 2-4. Using other driving systems

Cruise control .....	173
Dynamic radar cruise control.....	177
Intuitive parking assist .....	191
Driving assist systems.....	197
PCS (Pre-Collision System) .....	203

### 2-5. Driving information

Cargo and luggage.....	210
Vehicle load limits.....	213
Winter driving tips .....	214
Trailer towing.....	216
Dinghy towing .....	217

## 3 Interior features

### 3-1. Using the air conditioning system and defogger

Automatic air conditioning system .....	220
Rear window and outside rear view mirror defoggers.....	228
Windshield wiper de-icer .....	229

### 3-2. Using the audio system

Audio system type .....	230
Using the radio.....	233
Using the CD player.....	241
Playing back MP3 and WMA discs.....	248
Operating an iPod.....	256
Operating a USB memory.....	264
Optimal use of the audio system .....	273
Using the AUX port .....	275
Using the steering wheel audio switches.....	277

**3-3. Using the Bluetooth®****audio system**

Bluetooth® audio system ..... 280

Using the Bluetooth® audio  
system ..... 283Operating a Bluetooth®  
enabled portable player ..... 288Setting up a Bluetooth®  
enabled portable player ..... 292Bluetooth® audio system  
setup ..... 298**3-4. Using the hands-free phone  
system (for mobile phones)**Hands-free system for  
mobile phones ..... 299Using the hands-free system  
(for mobile phones) ..... 303

Making a phone call ..... 311

Setting a mobile phone ..... 315

Security and system setup ..... 320

Using the phone book ..... 324

**3-5. Using the interior lights**

Interior lights list ..... 330

• Interior lights ..... 332

• Personal lights ..... 332

**3-6. Using the storage features**

List of storage features ..... 334

• Glove box ..... 335

• Console box ..... 335

• Overhead console ..... 336

• Cup holders ..... 337

• Bottle holders/  
door pockets ..... 339

• Auxiliary box ..... 339

**3-7. Other interior features**

Sun visors ..... 340

Vanity mirrors ..... 341

Clock ..... 342

Satellite switches ..... 343

Ashtrays ..... 346

Cigarette lighter ..... 347

Power outlet ..... 348

Seat heaters ..... 349

Armrest ..... 351

Trunk storage extension ..... 352

Coat hooks ..... 354

Floor mat ..... 355

Trunk features ..... 356

Garage door opener ..... 359

Compass ..... 365

Safety Connect ..... 369

## 4 Maintenance and care

### 4-1. Maintenance and care

Cleaning and protecting the vehicle exterior .....	378
Cleaning and protecting the vehicle interior .....	381

### 4-2. Maintenance

Maintenance requirements.....	384
General maintenance .....	386
Emission inspection and maintenance (I/M) programs .....	389

### 4-3. Do-it-yourself maintenance

Do-it-yourself service precautions .....	390
Hood.....	393
Positioning a floor jack.....	394
Engine compartment.....	396
Tires .....	410
Tire inflation pressure.....	420
Wheels.....	424
Air conditioning filter .....	426
Electronic key battery .....	429
Checking and replacing fuses .....	431
Headlight aim .....	445
Light bulbs.....	447

## 5 When trouble arises

### 5-1. Essential information

Emergency flashers .....	454
If your vehicle needs to be towed .....	455
If you think something is wrong .....	461
Fuel pump shut off system .....	462

### 5-2. Steps to take in an emergency

If a warning light turns on or a warning buzzer sounds... ..	463
If a warning message is displayed.....	473
If you have a flat tire.....	487
If the engine will not start .....	496
If the shift lever cannot be shifted from P .....	497
If you lose your keys .....	498
If the electronic key does not operate properly .....	499
If the vehicle battery is discharged .....	502
If your vehicle overheats .....	505
If the vehicle becomes stuck.....	508
If your vehicle has to be stopped in an emergency.....	509

<b>6</b>	<b>Vehicle specifications</b>		<b>Index</b>
6-1.	Specifications		Abbreviation list..... 560
	Maintenance data (fuel, oil level, etc.).....	512	Alphabetical index ..... 562
	Fuel information.....	523	What to do if... ..... 573
	Tire information.....	526	
6-2.	Customization		
	Customizable features.....	538	
6-3.	Initialization		
	Items to initialize .....	543	
<b>7</b>	<b>For owners</b>		
	Reporting safety defects for U.S. owners.....	546	
	Seat belt instructions for Canadian owners (in French) .....	547	
	SRS airbag instructions for Canadian owners (in French) .....	549	

1

2

3

4

5

6

7